

§ 112.55–10

§ 112.55–10 Storage battery charging.

(a) Each storage battery installation for emergency lighting and power, and starting batteries for an emergency diesel or gas turbine driven generator set, must have apparatus to automatically maintain the battery fully charged.

(b) When the ship's service generating plant is available, the battery must have a continuous trickle charge, except that after discharge the battery must be charged automatically at a higher rate.

(c) Charging operations must not cause an absence of battery power.

(d) There must be instruments to show the rate of charge.

§ 112.55–15 Capacity of storage batteries.

(a) A storage battery for an emergency lighting and power system must have the capacity—

(1) To close all watertight doors two times;

(2) To open all watertight doors once; and

(3) To carry the remaining emergency loads continuously for the time prescribed in § 112.05–5(a), table 112.05–5(a).

(b) At the end of the time specified in paragraph (a) of this section, the potential of the storage battery must be at least 88 percent of the standard voltage.

[CGD 74–125A, 47 FR 15267, Apr. 8, 1982, as amended by CGD 94–108, 61 FR 28288, June 4, 1996; 61 FR 39695, July 30, 1996]

PART 113—COMMUNICATION AND ALARM SYSTEMS AND EQUIPMENT

Subpart 113.05—General Provisions

Sec.

113.05–5 Approved equipment.

113.05–7 Environmental tests.

Subpart 113.10—Fire and Smoke Detecting and Alarm Systems

113.10–1 Approved equipment.

113.10–3 Cable runs.

113.10–5 Common return.

113.10–7 Connection boxes.

113.10–9 Power supply.

46 CFR Ch. I (10–1–06 Edition)

Subpart 113.20—Automatic Sprinkler Systems

113.20–1 Sprinkler alarm system.

113.20–3 Connection boxes.

Subpart 113.25—General Emergency Alarm Systems

113.25–1 Applicability.

113.25–3 Requirements.

113.25–5 Location of contact makers.

113.25–6 Power supply.

113.25–7 Power supply overcurrent protection.

113.25–8 Distribution of general emergency alarm system feeders and branch circuits.

113.25–9 Location of general emergency alarm signal.

113.25–10 Emergency red-flashing lights.

113.25–11 Contact makers.

113.25–12 Alarm signals.

113.25–14 Electric cable and distribution fittings.

113.25–15 Distribution panels.

113.25–16 Overcurrent protection.

113.25–20 Marking of equipment.

113.25–25 General emergency alarm systems for manned ocean and coastwise barges.

113.25–30 General emergency alarm systems for barges of 300 or more gross tons with sleeping accommodations for more than six persons.

Subpart 113.27—Engineers' Assistance-Needed Alarm

113.27–1 Engineers' assistance-needed alarm.

Subpart 113.30—Internal Communications

113.30–1 Applicability.

113.30–3 Means of communications.

113.30–5 Requirements.

113.30–20 General requirements.

113.30–25 Detailed requirements.

Subpart 113.35—Engine Order Telegraph Systems

113.35–1 Definitions.

113.35–3 General requirements.

113.35–5 Electric engine order telegraph systems.

113.35–7 Electric engine order telegraph systems; operations.

113.35–9 Mechanical engine order telegraph systems.

113.35–13 Mechanical engine order telegraph systems; operation.

113.35–15 Mechanical engine order telegraph systems; application.

113.35–17 Vessels with navigating bridge control.

Coast Guard, DHS

§ 113.10-9

Subpart 113.37—Shaft Speed and Thrust Indicators

- 113.37-1 Applicability.
- 113.37-5 General requirements.
- 113.37-10 Detailed requirements.

Subpart 113.40—Rudder Angle Indicator Systems

- 113.40-1 Applicability.
- 113.40-5 General requirements.
- 113.40-10 Detailed requirements.

Subpart 113.43—Steering Failure Alarm Systems

- 113.43-1 Applicability.
- 113.43-3 Alarm system.
- 113.43-5 Power supply.

Subpart 113.45—Refrigerated Spaces Alarm Systems

- 113.45-5 General requirements.

Subpart 113.50—Public Address Systems

- 113.50-1 Applicability.
- 113.50-5 General requirements.
- 113.50-10 Additional requirements for passenger vessels.
- 113.50-15 Loudspeakers.
- 113.50-20 Distribution of cable runs.

Subpart 113.65—Whistle Operators

- 113.65-5 General requirements.

AUTHORITY: 46 U.S.C. 3306, 3703; Department of Homeland Security Delegation No. 0170.1.

SOURCE: CGD 74-125A, 47 FR 15272, Apr. 8, 1982, unless otherwise noted.

Subpart 113.05—General Provisions

§ 113.05-5 Approved equipment.

If approved equipment is required in this part, that equipment must be specifically approved by the Commandant.

NOTE: Many specifications for equipment that must be approved are in Subchapter Q for this chapter.

§ 113.05-7 Environmental tests.

Communication, alarm system, control, and monitoring equipment must meet the environmental tests of—

- (a) Table 4/11.1 of ABS Rules for Building and Classing Steel Vessels or the applicable ENV category of Lloyd's Register Type approval System—Test Specification No. 1; and

- (b) IEC 533 as appropriate.

[CGD 94-108, 61 FR 28288, June 4, 1996, as amended at 62 FR 23910, May 1, 1997]

Subpart 113.10—Fire and Smoke Detecting and Alarm Systems

§ 113.10-1 Approved equipment.

Each alarm annunciator, fire detector, test station, manual station, and vibrating bell must be approved under Subpart 161.002 of this chapter and meet the requirements of this subpart.

§ 113.10-3 Cable runs.

Cable runs between the fire alarm annunciator and fire detecting or fire alarm zones must be as direct as practicable and, where practicable, must not be in staterooms, lockers, or other enclosed spaces in order to reduce the risk of damage by a localized fire or other cause.

§ 113.10-5 Common return.

A conductor must not be used as a common return from more than one zone.

§ 113.10-7 Connection boxes.

Each connection box must be constructed in accordance with NEMA 250 Type 4 or 4X or IEC IP 56 requirements.

[CGD 94-108, 61 FR 28288, June 4, 1996, as amended at 62 FR 23910, May 1, 1997]

§ 113.10-9 Power supply.

(a) *General.* There must be at least two sources of power for the electrical equipment of each fire detecting and alarm system. The normal source must be the main power source. The other source must be the emergency power source or an automatically charged battery. If the other source is an automatically charged battery, the charger must be supplied from the final emergency power source. Upon loss of power to the system from the normal source, the system must be automatically supplied from the other source.

(b) *Batteries.* Each battery used in a fire detecting and alarm system must meet Subpart 111.15 of this chapter.

(c) *Capacity of power supply branch circuit.* The capacity of each branch circuit providing power to a fire detection

§ 113.20-1

or alarm system must not be less than 125 percent of the maximum load.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28288, June 4, 1996]

Subpart 113.20—Automatic Sprinkler Systems

§ 113.20-1 Sprinkler alarm system.

Each sprinkler alarm system, including annunciator, power supply, alarm switches, and bells, must meet Subpart 76.25 of this chapter.

§ 113.20-3 Connection boxes.

Each connection box and each switch enclosure in an automatic sprinkler system must be constructed in accordance with NEMA 250 Type 4 or 4X or IEC IP 56 requirements.

[CGD 94-108, 61 FR 28288, June 4, 1996, as amended at 62 FR 23910, May 1, 1997]

Subpart 113.25—General Emergency Alarm Systems

EDITORIAL NOTE: Nomenclature changes to subpart 113.25 appear at 61 FR 28288, June 4, 1996.

§ 113.25-1 Applicability.

(a) This subpart, except §§113.25-25 and 113.25-30, applies to each manned vessel of over 100 gross tons, except barges, scows, and similar vessels.

(b) Section 113.25-25 applies to each manned ocean and coastwise barge of over 100 gross tons if the crew is divided into watches for the purpose of steering.

(c) Section 113.25-30 applies to each barge of 300 or more gross tons that has sleeping accommodations for more than six persons.

§ 113.25-3 Requirements.

Each vessel must have a general emergency alarm system that meets the requirements of this subpart.

§ 113.25-5 Location of contact makers.

(a) *Passenger vessels and cargo and miscellaneous vessels.* Each passenger vessel, cargo vessel, and miscellaneous vessel must have a manually operated

46 CFR Ch. I (10-1-06 Edition)

contact maker for the general emergency alarm system:

(1) In the navigating bridge; and
(2) At the feeder distribution panel if the general alarm power supply is not in or next to the navigating bridge.

(b) *Tank vessels.* Each tank vessel must have a manually operated contact maker for the general emergency alarm system:

(1) In the navigating bridge;
(2) At the deck officers' quarters farthest from the engineroom;
(3) in the engineroom;
(4) At the location of the emergency means of stopping cargo transfer required under 33 CFR 155.780; and

(5) At the feeder distribution panel if the general alarm power supply is not in or next to the navigating bridge.

(c) *Mobile offshore drilling units.* Each mobile offshore drilling unit must have a manually operated contact maker for the general emergency alarm system:

(1) In the main control room;
(2) At the drilling console;
(3) At the feeder distribution panel;
(4) In the navigating bridge, if a navigating bridge is installed; and
(5) In a routinely occupied space that is as far as practicable from all other contact makers.

(d) *Additional contact maker.* A vessel must not have more than one other contact maker that operates the general emergency alarm system in addition to those required under paragraph (a), (b), or (c) of this section unless the installation of other contact makers has been accepted by the Commandant.

(e) *Special system.* If a vessel has an emergency squad when operating, has a manual fire alarm system, or is an ocean-going passenger vessel, it must have:

(1) An independent manually operated contact maker in the navigating bridge that is connected to operate only the general emergency alarm signal in crew's quarters and machinery spaces; or

(2) A separate alarm system that sounds in the crew's quarters and machinery spaces.

§ 113.25-6 Power supply.

(a) The power supply for the general emergency alarm system must meet

the requirements of SOLAS 74, regulations III-6.4.2 and III/50.

(b) The emergency power source for the general emergency alarm system must meet the requirements of SOLAS 74, regulation II-1/42 or II-1/43, as applicable.

[CGD 94-108, 61 FR 28288, June 4, 1996]

§ 113.25-7 Power supply overcurrent protection.

(a) If the general emergency alarm system is the only load supplied by the general emergency alarm system battery or batteries, the battery or batteries must have an enclosed fused switch or circuit breaker that has a means of locking. The fused switch or circuit breaker must be outside of, and next to, the battery room or battery locker, and the capacity of the fuses or circuit breaker must be at least 200 percent of the connected load.

(b) If the general emergency alarm system is supplied from an emergency or interior communication switchboard, or if duplicate general alarm batteries supply other loads as allowed under § 113.25-6(e)(2), there must be a fused switch or circuit breaker supplying the general emergency alarm system that has a means of locking.

§ 113.25-8 Distribution of general emergency alarm system feeders and branch circuits.

(a) Each system must have a feeder distribution panel to divide the system into the necessary number of zone feeders, except where, because of the arrangement of the vessel, only one zone feeder is necessary; then a branch circuit distribution panel or feeder distribution panel must be used.

(b) The feeder distribution panel must have overcurrent protection for each zone feeder, but there must be no disconnect switches.

(c) The feeder distribution panel must be in an enclosed space next to the general alarm power supply.

(d) Each system must have at least one feeder for each vertical fire zone that has general emergency alarm signal.

(e) Each system must have one or more branch circuit distribution panels for each zone feeder, with at least one fused branch circuit for each deck

level. The distribution panel must be above the uppermost continuous deck, in the zone served, and there must be no disconnect switches for the branch circuits.

(f) A branch circuit must not supply emergency alarm signal on more than one deck level, except for a single branch circuit supplying all levels of a single space containing more than one deck level if all other requirements of this section are met.

(g) On a vessel not divided into fire zones by main vertical fire bulkheads, the general emergency alarm system must be arranged into vertical service zones not more than 40 meters (131 feet) long, and there must be a general alarm feeder for each of these zones that has general emergency alarm signal.

(h) General alarm feeders and branch circuit cables must be in passageways and must not be in staterooms, lockers, galleys, machinery spaces, or other enclosed spaces, unless it is necessary to supply general emergency alarm signal in those spaces.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28288, June 4, 1996]

§ 113.25-9 Location of general emergency alarm signal.

General emergency alarm signal must:

(a) Be located in passenger and crew quarters areas where they can alert persons in spaces where those persons may be maintaining, repairing, or operating equipment, stowing or drawing stores or equipment, or transiting, such as public spaces, work spaces, machinery spaces, workshops, galleys, emergency firepump room, bow thruster rooms, storage areas for paint, rope, and other stores, underdeck passageways in cargo areas, steering gear rooms, windless rooms, holds of roll-on/roll-off vessels, and, except those that are accessible only through bolted manhole covers, duct keels with valve operators; and

(b) Be audible in the spaces identified in paragraph (a) of this section with all normally closed doors and accesses closed; and

(c) Be installed in cabins without loudspeaker installation. Other audible

§ 113.25-10

devices, such as electronic alarm transducers, are permitted.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28288, June 4, 1996]

§ 113.25-10 Emergency red-flashing lights.

(a) In a space described in §113.25-9(a), where the general emergency alarm signal cannot be heard over the background noise, there must be a red-flashing light or rotating beacon, in addition to the general emergency alarm signal, that:

(1) Has sufficient intensity above the background lighting that would alert personnel in the space;

(2) Is activated whenever the general emergency alarm signal in the space are activated; and

(3) Is supplied by the general emergency alarm system power supply or the vessel emergency power source through a relay that is operated by the general emergency alarm system.

(b) A red-flashing light or rotating beacon must be installed so that it is visible in the cargo pump rooms of vessels that carry combustible liquid cargoes. The installation must be in accordance with the requirements of part 111, subpart 111.105, of this chapter.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28288, June 4, 1996; 62 FR 23910, May 1, 1997]

§ 113.25-11 Contact makers.

Each contact maker must—

(a) Have normally open contacts and be constructed in accordance with NEMA 250 Type 4 or 4X or IEC IP 56 requirements;

(b) Have a switch handle that can be maintained in the “on” position;

(c) Have the “off” and “on” positions of the operating handle permanently marked; and

(d) Have an inductive load rating not less than the connected load or, on large vessels, have auxiliary devices to interrupt the load current.

[CGD 94-108, 61 FR 28288, June 4, 1996, as amended at 62 FR 23910, May 1, 1997]

§ 113.25-12 Alarm signals.

(a) Each general emergency alarm signal must be an electrically-operated

46 CFR Ch. I (10-1-06 Edition)

bell, klaxon, or other warning device capable of producing a signal or tone distinct from any other audible signal on the vessel.

(b) Electronic devices used to produce the general emergency alarm signal must meet the requirements of subpart 113.50 of this part.

(c) The minimum sound pressure levels for the emergency alarm tone in interior and exterior spaces must be 80 dB(A) and at least 10 dB(A) above ambient noise levels existing during normal equipment operation with the vessel underway in moderate weather.

[CGD 94-108, 61 FR 28289, June 4, 1996]

§ 113.25-14 Electric cable and distribution fittings.

Each cable entrance to an emergency alarm signal or distribution fitting must be made watertight by a terminal or stuffing tube.

§ 113.25-15 Distribution panels.

Each distribution panel must:

(a) Be watertight;

(b) Need a tool to be opened.

§ 113.25-16 Overcurrent protection.

(a) Each fuse in a general emergency alarm system must meet the requirements of part 111, subpart 111.53, of this chapter.

(b) Each overcurrent protection device must cause as wide a differential as possible between the rating of the branch circuit overcurrent protection device and that of the feeder overcurrent protection device.

(c) The capacity of the feeder overcurrent device must be as near practicable to 200 percent of the load supplied. The capacity of a branch circuit overcurrent device must not be higher than 50 percent of the capacity of the feeder overcurrent device.

[CGD 94-108, 61 FR 28289, June 4, 1996]

§ 113.25-20 Marking of equipment.

(a) Each general emergency alarm system fused switch and distribution panel must have a fixed nameplate on the outside of its cover that has a description of its function. The rating of fuses must also be shown on the outside of the cover of a fused switch.

Coast Guard, DHS

§ 113.30-3

(b) Each general alarm contact maker must be marked "GENERAL ALARM" in red letters on a corrosion-resistant plate or on a sign.

(c) A contact maker that operates only the general emergency alarm signal in crew quarters, machinery spaces, and work spaces must be marked "CREW ALARM" by the method described in paragraph (b) of this section.

(d) Each general emergency alarm signal must be marked "GENERAL ALARM—WHEN EMERGENCY ALARM SIGNAL RINGS GO TO YOUR STATION" in red letters at least ½ inch high.

(e) Each general emergency alarm system distribution panel must have a directory attached to the inside of its cover giving the designation of each circuit, the area supplied by each circuit, and the rating of each circuit fuse.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by USCG-2004-18884, 69 FR 58348, Sept. 30, 2004]

§ 113.25-25 General emergency alarm systems for manned ocean and coastwise barges.

A manned ocean or coastwise barge of more than 100 gross tons, if it is one that operates with the crew divided into watches for steering the vessel, must have an emergency alarm signal installation. The system must:

(a) Have an automatically charged battery as the power source;

(b) Have a manually operated contact maker at the steering station and in the crew accommodation area; and

(c) Must meet the requirements of § 113.25.7 and §§ 113.25-9 through 113.25-20 of this subpart.

§ 113.25-30 General emergency alarm systems for barges of 300 or more gross tons with sleeping accommodations for more than six persons.

The general emergency alarm system for a barge of 300 or more gross tons with sleeping accommodations for more than six persons must meet the requirements of Subpart 113.25, except as follows:

(a) The number and location of contact makers must be determined by the

design, service, and operation of the barge.

NOTE: Contact makers in the primary work area, quarters area, galley and mess area, machinery spaces, and the navigating bridge or control area should be considered.

(b) If a distribution panel cannot be above the uppermost continuous deck because of the design of the barge and is installed below the deck, it must be as near the deck as practicable.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28289, June 4, 1996]

Subpart 113.27—Engineers' Assistance-Needed Alarm

§ 113.27-1 Engineers' assistance-needed alarm.

Each self-propelled ocean, Great Lakes, or coastwise vessel must have a manually-operated engineers' assistance-needed alarm that is:

(a) Operated from:

(1) The engine control room, if the vessel has an engine control room; or

(2) The maneuvering platform, if the vessel has no engine control room;

(b) Audible in the engineers' accommodation spaces; and

(c) Powered from the general alarm power source.

Subpart 113.30—Internal Communications

§ 113.30-1 Applicability.

This subpart applies to each self-propelled vessel.

§ 113.30-3 Means of communications.

(a) An emergency means of communication required by this subpart must—

(1) Be comprised of either fixed or portable equipment; and

(2) Provide common talking means of two-way voice communication and calling among the navigating bridge, emergency control stations, muster stations, embarkation stations, and other strategic positions listed in § 113.30-5.

(b) The means of communication and calling must be a sound-powered telephone or other reliable voice communication method and must be independent of the vessel's electrical system.

[CGD 94-108, 61 FR 28289, June 4, 1996]

§ 113.30-5 Requirements.

(a) *Communication.* Each vessel must have a means of communication among the following:

- (1) Navigating bridge.
- (2) Steering gear room, if outside the engineroom.
- (3) Alternative steering station if outside of the steering gear room.
- (4) Engine control room, if the vessel has an engine control room.
- (5) Maneuvering platform, if the vessel has no engine control room.
- (6) Control room, if the vessel is a mobile offshore drilling unit.
- (7) The engineering officers' accommodations, if the vessel is an automated, self-propelled vessel under § 62.50-20(f) of this chapter.

(b) *Gyrocompass.* Each vessel that has a master gyrocompass that is not in or next to the navigating bridge must have a means of communication between the master gyrocompass and the navigating bridge repeater compass.

(c) *Radar.* Each vessel that has a radar plan position indicator that is not in or next to the navigating bridge must have a means of communication between the navigating bridge and the radar plan position indicator.

(d) *Emergency lockers.* If the emergency equipment lockers or spaces used by the emergency squad are not next to the navigating bridge or, on a mobile offshore drilling unit, next to the control room, there must be a means of communication between the navigating bridge or control room and the emergency equipment lockers or spaces.

(e) *Radio and radio direction finder.* Communication to the radio and radio direction finder must meet the following requirements:

- (1) Each vessel that has a radio installation must have a means of communication between the radio room, the navigating bridge, or, if the vessel is a mobile offshore drilling unit, the control room, and any other place from

which the vessel may be navigated under normal conditions, other than a place that is only for emergency functions, a place that is only for docking or maneuvering, or a place that is for navigating the vessel in close quarters. A location that has the apparatus that is necessary to steer the vessel, give engine orders, and control the whistle, is a place from which the vessel may be navigated.

(2) If the operating position of the emergency radio installation is not in the compartment normally used for operating the main radio installation, there must be means of communication between the emergency radio room, the navigating bridge, or, if the vessel is a mobile offshore drilling unit, the control room, and any other place from which the vessel may be navigated under normal conditions; other than a place that is only for emergency functions, a place that is only for docking or maneuvering, or a place that is for navigating the vessel in close quarters.

(3) Each vessel equipped with radio direction-finding apparatus that is not in or next to the navigating bridge must have a means of communication between the navigating bridge and the direction-finding apparatus.

(4) The communication system required by this paragraph must be independent of all other systems on the vessel. The location of the termination of these systems is subject to approval by the Federal Communication Commission.

(f) *Fire or smoke detecting systems.* Each vessel equipped with a fire or smoke detecting system, if control units are not in the navigating bridge, must have means of communication between the navigating bridge and the stations where the control units are located.

(g) *Lookout.* Each vessel must have a means of communication between the navigating bridge and the bow or forward lookout station unless direct voice communication is possible.

(h) *Engineroom local control station.* Each self-propelled vessel equipped with control from the navigating bridge must have a means of communication between the local station for the control of the speed or direction of thrust of the propulsion machinery and

the engine control room, unless an engine order telegraph is installed in accordance with § 113.35-3. Each communication station at a local control station must—

(1) Be on a circuit separate from any other station required by this section; and

(2) Provide the capability of reliable voice communication when the vessel is underway.

(i) *Mobile offshore drilling units.* Each non-self-propelled mobile offshore drilling unit must have a means of communication among the control room, drill floor, machinery space, and silicon controlled rectifier (SCR) room (if installed). Each column-stabilized mobile offshore drilling unit must have a means of communication between the ballast control room and the spaces that contain the ballast pumps and valves.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28289, June 4, 1996; 62 FR 23910, May 1, 1997; USCG-2004-18884, 69 FR 58348, Sept. 30, 2004]

§ 113.30-20 General requirements.

(a) The communications stations listed in § 113.30-5(a) through (d), (f), (g), and (i) and other communications stations for the operation of the vessel, such as the captain's and chief engineer's offices and staterooms, emergency power room, carbon dioxide (or other extinguishing agent) control room, and firepump room, must not be on the same circuit as communications stations installed to meet the requirements of §§ 113.30-5(e) and 113.30-5(h).

(b) If a communications station is in the weather and on the same circuit as other required stations, there must be a cut-out switch on the navigating bridge that can isolate this station from the rest of the stations, unless the system possesses other effective means of station isolation during a fault condition.

(c) Jack boxes or headsets must not be on a communications system that includes any station required by this subpart, except for a station installed to meet §§ 113.30-5(h) or 113.30-25(d).

[CGD 94-108, 61 FR 28289, June 4, 1996]

§ 113.30-25 Detailed requirements.

(a) Each sound-powered telephone station must include a permanently-wired handset with a push-to-talk button and a hanger for the handset, except those stations detailed in paragraph (d) of this section. The hanger must be constructed so that it holds the handset away from the bulkhead and so that the handset will not be dislodged by the motion of the vessel.

(b) Each voice communication station device in the weather must be in a proper enclosure as required in § 111.01-9 of this chapter. The audible signal device must be outside the station enclosure.

(c) Each station in a navigating bridge or a machinery space must be in an enclosure meeting at least NEMA 250 Type 2 or IEC IP 22 requirements.

(d) In a noisy location, such as an engine room, there must be a booth or other equipment to permit reliable voice communication during vessel operation.

(e) In a location where the voice communication station audible signal device cannot be heard throughout the space, there must be an additional audible signal device or visual device, such as a light, which is energized from the final emergency bus.

(f) If two or more voice communication stations are near each other, there must be a means that indicates the station called.

(g) Each voice communication talking circuit must be electrically independent of each calling circuit. A short circuit, open circuit, or ground on either side of a calling circuit must not affect a talking circuit. Circuits must be insulated from ground.

(h) Each connection box must meet at least NEMA 250 Type 4 or 4X or IEC IP 56 requirements.

(i) Voice communication cables must run as close to the fore and aft centerline of the vessel as practicable. The cable must not run through high fire-risk spaces, such as machinery rooms and galleys, unless it is technically impractical to route them otherwise or they are required to serve circuits in the high-risk area. Cable running

§ 113.35-1

through or into these high-risk areas must meet the requirements of EC 331.

[CGD 94-108, 61 FR 28289, June 4, 1996; 61 FR 33045, June 26, 1996; 61 FR 36787, July 12, 1996, as amended at 62 FR 23910, May 1, 1997]

Subpart 113.35—Engine Order Telegraph Systems

§ 113.35-1 Definitions.

As used in this subpart:

(a) *Indicator* means an instrument in the engine room to receive and acknowledge engine orders; and

(b) *Transmitter* means an instrument to send engine orders to the engineroom and receive acknowledgment from the engineroom.

§ 113.35-3 General requirements.

(a) Each self-propelled vessel, except as provided in paragraph (d) of this section, must have an electric or mechanical engine order telegraph system from the navigating bridge to the engineroom.

(b) On a vessel with more than one propulsion engine, each engine must have this system.

(c) On a double-ended vessel that has two navigating bridges, this system must be between the engineroom and each navigating bridge.

(d) If a small vessel has no engine order telegraph system between the navigating bridge and the engineroom, the propulsion plant must be controlled entirely from the navigating bridge, with no means of normal engine control from the engineroom.

(e) On vessels equipped with pilot-house control, each local control station in the engineroom must have an indicator if:

(1) Manual operation from the local control station is an alternative means of control; and

(2) The local control station is not immediately adjacent to the engineroom control station; and

(3) Reliable voice communication and calling that meets the requirements of § 113.30-5(h) is not provided.

(f) Engine order telegraph and remote propulsion control systems must be electrically separate and independent, except that a single mechanical operator control device with separate

46 CFR Ch. I (10-1-06 Edition)

transmitters and connections for each system may be used.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 81-030, 53 FR 17847, May 18, 1988; CGD 94-108, 61 FR 28290, June 4, 1996]

§ 113.35-5 Electric engine order telegraph systems.

(a) Each electric engine order telegraph system must have transmitters and indicators that are electrically connected to each other.

(b) Each engineroom indicator must be capable of acknowledgment of orders.

(c) There must be an audible signal at each instrument. The signal at both locations must sound continuously when the transmitter and the indicator do not show the same order.

(d) Each telegraph instrument must meet the protection requirements of § 111.01-9 of this chapter.

(e) Each system must have an alarm which—

(1) Automatically sounds and visually signals a loss of power to the system;

(2) Is on the navigating bridge; and

(3) Has a means to reduce the audible signal from 100 percent to not less than 50 percent.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28290, June 4, 1996]

§ 113.35-7 Electric engine order telegraph systems; operations.

(a) Where two or more transmitters, located on or on top of, or on the wings of, the navigating bridge operate a common indicator in the engineroom, the transmitters must:

(1) Operate in synchronism as required in paragraph (b) of this section; or

(2) Operate under the control of a transmitter transfer control in accordance with paragraph (c) of this section.

(b) All transmitter handles and pointers must operate in synchronism. Where the transmitters are mechanically interlocked to effect synchronous operation, the requirements of § 113.35-13 must be met.

(c) Except for a transmitter in an unattended navigating bridge on a double-ended vessel, each transmitter must operate under the control of a

Coast Guard, DHS

§ 113.40-1

transmitter transfer control so that movement of any one transmitter handle automatically connects that transmitter electrically to the engineroom indicator and simultaneously disconnects electrically all other transmitters. The reply pointers of all transmitters must operate in synchronism at all times.

(d) On a double-ended vessel that has two navigating bridges, a manually operated transfer switch which will disconnect the system in the unattended navigating bridge must be provided.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982. Redesignated and amended by CGD 94-108, 61 FR 28290, June 4, 1996]

§ 113.35-9 Mechanical engine order telegraph systems.

(a) Each mechanical engine order telegraph system must consist of transmitters and indicators mechanically connected to each other, as by means of chains and wires.

(b) Each transmitter and each indicator must have an audible signal device to indicate, in the case of an indicator, the receipt of an order, and in the case of a transmitter, the acknowledgment of an order. The audible signal device must not be dependent upon any source of power for operation other than that of the movement of the transmitter or indicator handle.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28290, June 4, 1996]

§ 113.35-13 Mechanical engine order telegraph systems; operation.

If more than one transmitter operates a common indicator in the engineroom, all the transmitters must be mechanically interlocked and operate in synchronism. A failure of the transmission wire or chain at any transmitter must not interrupt or disable any other transmitter.

§ 113.35-15 Mechanical engine order telegraph systems; application.

If a mechanical engine order telegraph system is installed on any vessel to provide the communication required by this subpart, the length of cables or other mechanical limitations must not prevent the efficient operation of the system.

§ 113.35-17 Vessels with navigating bridge control.

Each vessel with navigating bridge throttle control must have a positive mechanical stop on each telegraph transmitter that prevents movement to the "Navigating Bridge Control" position without positive action by the operator.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28290, June 4, 1996]

Subpart 113.37—Shaft Speed and Thrust Indicators

§ 113.37-1 Applicability.

This subpart applies to all self-propelled vessels.

§ 113.37-5 General requirements.

(a) A vessel equipped with fixed pitch propellers must have on the navigating bridge and at the engineroom control station a propeller speed and direction indicator for each shaft.

(b) A vessel equipped with controllable pitch propellers must have on the navigating bridge and at the engineroom control station a propeller speed and pitch position indicator for each shaft.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28290, June 4, 1996]

§ 113.37-10 Detailed requirements.

(a) Each indicator must be independent of the propulsion control system. A failure of the propulsion control system must not affect the operation of the indicators.

(b) Each electric component or its enclosure must meet NEMA 250 Type 4 or 4X or IEC IP 56 requirements.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28290, June 4, 1996]

Subpart 113.40—Rudder Angle Indicator Systems

§ 113.40-1 Applicability.

This subpart applies to self-propelled vessels.

§ 113.40-5

§ 113.40-5 General requirements.

The position of the rudder, if power-operated, must be shown at the principal steering station. If there is non-follow-up steering control at the alternative steering station, there must be a separate rudder angle indicator system for that station that is electrically independent from each other rudder angle indicator system.

§ 113.40-10 Detailed requirements.

(a) Each rudder angle indicator system must have a transmitter at the rudder head that is actuated by movement of the rudder with the angular movements of the rudder transmitted to a remote indicator or indicators. This system must be independent of all other systems and not receive power or signal from the steering gear control, autopilot, or dynamic positioning systems. However, the indicator may be physically located on a control console, such as an integrated bridge system, if it is readily visible by the helmsman at the steering stand.

(b) Each electric component or its enclosure must meet NEMA 250 Type 4 or 4X or IEC IP 56 requirements.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28290, June 4, 1996; 62 FR 23910, May 1, 1997]

Subpart 113.43—Steering Failure Alarm Systems

§ 113.43-1 Applicability.

This subpart applies to each vessel of 1600 gross tons and over that has power driven main or auxiliary steering gear.

§ 113.43-3 Alarm system.

(a) Each vessel must have a steering failure alarm system that actuates an audible and visible alarm in the pilot-house when the actual position of the rudder differs by more than 5 degrees from the rudder position ordered by the followup control systems, required by part 58, subpart 58.25, of this chapter, for more than:

- (1) 30 seconds for ordered rudder position changes of 70 degrees;
- (2) 6.5 seconds for ordered rudder position changes of 5 degrees; and
- (3) The time period calculated by the following formula for ordered rudder

46 CFR Ch. I (10-1-06 Edition)

positions changes between 5 degrees and 70 degrees:

$$t = (R/2.76) + 4.64$$

Where

t = maximum time delay in seconds

R = ordered rudder change in degrees

(b) The alarm system must be separate from, and independent of, each steering gear control system, except for input received from the steering wheel shaft.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 62 FR 23910, May 1, 1997; USCG-2004-18884, 69 FR 58348, Sept. 30, 2004]

§ 113.43-5 Power supply.

Each steering failure alarm system must be supplied by a circuit that:

(a) Is independent of other steering gear system and steering alarm circuits;

(b) Is fed from the final emergency power source through the emergency distribution panel in the wheelhouse, if installed; and

(c) Has no overcurrent protection except short-circuit protection by an instantaneous fuse or circuit breaker rated or set at 400 to 500 percent of:

- (1) The current-carrying capacity of the smallest alarm system interconnecting conductors; or
- (2) The normal load of the system.

Subpart 113.45—Refrigerated Spaces Alarm Systems

§ 113.45-5 General requirements.

(a) Each refrigerated space that is accessible to the vessel's personnel and that can be locked from the outside so that it cannot be opened from the inside, must have an audible alarm system that can be operated from within the refrigerated space.

(b) The alarm activator must be in the refrigerated space at its exit.

(c) The audible signal must sound at a manned location.

(d) If there is a common audible signal for more than one lockable refrigerated space, there must be an annunciator for locating the space from which the signal was initiated.

Subpart 113.50—Public Address Systems

§ 113.50-1 Applicability.

This subpart applies to each vessel required to have a general emergency alarm system in accordance with § 113.25-1.

[CGD 94-108, 61 FR 28290, June 4, 1996]

§ 113.50-5 General requirements.

(a) Each vessel must have an amplifier-type announcing system that will supplement the general emergency alarm. This system must provide for the transmission of orders and information throughout the vessel by means of microphones and loudspeakers connected through an amplifier. If a decentralized-type system is used, its overall performance must not be affected by the failure of a single call station. This system may be combined with the general emergency alarm and fire detecting and alarm systems. The public address system must be protected against unauthorized use.

(b) The announcing station must be located adjacent to the general emergency alarm contact maker on the navigating bridge.

(c) There must be a means to silence all other audio distribution systems at the announcing station.

(d) The system may be arranged to allow broadcasting separately to, or to any combination of, various areas on the vessel. If the amplifier system is used for the general emergency alarm required by subpart 113.25 of this part, the operation of a general emergency alarm contact maker must activate all speakers in the system, except that a separate crew alarm may be used as allowed by § 113.25-5(e)(2).

(e) The amplifier, and any device used to produce the general emergency alarm signal, must be provided in duplicate.

(f) The power supply must be in accordance with the requirements of §§ 113.25-6 and 113.25-7.

(g) Each electrical subsystem in a weather location must be watertight or in a watertight enclosure (NEMA 250 Type 4 or 4X or IEC IP 56).

[CGD 94-108, 61 FR 28290, June 4, 1996, as amended at 62 FR 23910, May 1, 1997]

§ 113.50-10 Additional requirements for passenger vessels.

Each passenger vessel must have a public address system capable of broadcasting separately or collectively to the following stations:

- (a) Survival craft stations, port.
- (b) Survival craft stations, starboard.
- (c) Survival craft embarkation stations, port.
- (d) Survival craft embarkation stations, starboard.
- (e) Public spaces used for passenger assembly points.
- (f) Crew quarters.
- (g) Accommodation spaces and service spaces.

[CGD 94-108, 61 FR 28290, June 4, 1996]

§ 113.50-15 Loudspeakers.

(a) Loudspeakers must be located to eliminate feedback or other interference which would degrade communication.

(b) Loudspeakers must be located to provide intelligible and audible one-way communication throughout the vessel. Weatherdeck loudspeakers must be watertight and suitably protected from the effects of the wind and seas.

(c) There must be a sufficient number of loudspeakers throughout the vessel. The public address system must be installed with regard to acoustically marginal conditions and not require any action from the addressee. With the vessel underway in normal conditions, the minimum sound pressure levels for broadcasting emergency announcements must be—

(1) In interior spaces, 75 dB(A) or, if the background noise level exceeds 75 dB(A), then at least 20 dB(A) above maximum background noise level; and

(2) In exterior spaces, 80 dB(A) or, if the background noise level exceeds 80 dB(A), then at least 15 dB(A) above maximum background noise level.

(d) Loudspeakers must not have external volume controls or local cutout switches.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28291, June 4, 1996; 61 FR 36787, July 12, 1996]

§ 113.50-20 Distribution of cable runs.

(a) Each system must have a feeder distribution panel to divide the system

§ 113.65-5

into the necessary number of zone feeders. Where, because of the arrangement of the vessel, only one zone feeder is necessary, a branch circuit distribution panel must be used.

(b) The feeder distribution panel must be in an enclosed space next to the public address system power supply.

(c) Each system must have at least one feeder for each vertical fire zone.

(d) Each system must have one or more branch circuit distribution panels for each zone feeder, with at least one branch circuit for each deck level. The distribution panel must be above the uppermost continuous deck, in the zone served, and there must be no disconnect switches for the branch circuits.

(e) A branch circuit must not supply speakers on more than one deck level, except for a single branch circuit supplying all levels of a single space if all

46 CFR Ch. I (10-1-06 Edition)

other requirements of this section are met.

(f) On a vessel not divided into vertical fire zones by main vertical fire bulkheads, the vessel must be divided into vertical zones not more than 40 meters (131 feet) long. There must be a feeder for each of these zones.

(g) Feeders and branch circuit cables must be in passageways. They must not be in staterooms, lockers, galleys, or machinery spaces, unless it is necessary to supply public address speakers in those spaces.

[CGD 94-108, 61 FR 28291, June 4, 1996]

Subpart 113.65—Whistle Operators

§ 113.65-5 General requirements.

Each whistle operator must meet section 37.19 of IEEE Standard No. 45.

[CGD 74-125A, 47 FR 15272, Apr. 8, 1982, as amended by CGD 82-036, 48 FR 655, Jan. 6, 1983; CGD 94-108, 61 FR 28291, June 4, 1996]

INDEX

SUBCHAPTER J—ELECTRICAL ENGINEERING

EDITORIAL NOTE: This listing is provided for informational purposes only. It is compiled by and kept current by the U.S. Coast Guard, Department of Homeland Security.

Part, subpart, or section

A

Accessibility: General Requirements	111.01-7
Air heating equipment	111.87
Alarms:	
Engine order telegraph	113.35-5
Engineers' assistance needed	113.27
Environmental tests	113.05-7
Fire and smoke detecting and alarm systems	113.10
General emergency alarm systems	113.25
Refrigerated spaces	113.45-5
Semiconductor rectifier temperature	111.33-7, 111.33-11
Sprinkler system	113.20
Steering failure	113.43
Submerged cargo pump motors	111.105-31(d), 111.105-31(e)(2), 111.105-32(e)
Ventilation loss	111.105-33(f)(1), 111.105-39(a)
American Bureau of Shipping: Rules	110.10-1(b)
American National Standard Safety Code for Elevators, Dumbwaiters, and Escalators, and Moving Walks. (See American National Standards Institute)	
American National Standards Institute: Standards	110.10-1(b)
American Society for Testing and Materials: Standards	110.10-1(b)
American Society of Mechanical Engineers. (See American National Standards Institute)	
Ammeters: Generators	111.30-25(b), 111.30-27
Ammonia carriers	111.105-32
Anesthetics, flammable	111.105-37
Appliances	111.77
Grounding	111.05
Overcurrent protection	111.77-1
Receptacle outlets	111.79
Applicability of this subchapter	110.01
Armored cable. (See Cable, armored)	
Attachment plugs. (See Receptacles)	
Automatic emergency lighting and power system, definition of	112.01-10
Automatic fire detecting and alarm system. (See Fire detecting and alarm system)	
Automatic sprinkler systems. (See Sprinkler systems)	
Autotransformers	111.20-10

B

Batteries, storage	111.15
Box linings	111.15-5(g)
Boxes	111.15-5

46 CFR Ch. I (10–1–06 Edition)

Categories.....	111.15-3
Conductors.....	111.15-20
Construction.....	111.15-2
Electric starting.....	112.50-5
Emergency lighting and power source.....	112.05-5, 112.30, 112.35, 112.37, 112.45, 112.50-5, 112.55
Engine starting.....	111.05-11(a)(2)
Installation.....	111.15-5
Nameplates.....	111.15-5(e)
Overload protection.....	111.15-25
Reverse current protection.....	111.15-25
Room and locker.....	111.15-5(f)
Rooms, hazardous locations.....	111.15-5(a), 111.105-41
Trays.....	111.15-5(d)
Ventilation.....	111.15-10
Battery chargers.....	111.15-30
Belt drives.....	111.105-27
Berth lights.....	111.75-15(d)
Berthing compartments, lighting of.....	111.75-15(a)
Bilge pumps, submersible.....	111.101
Source of power.....	112.15-5(d)
Boat winches, power operated.....	111.95
Boxes:	
Fire detecting and alarm systems.....	113.10-7
Shore connection.....	111.83
Sound powered telephone system.....	113.30-25(h)
Sprinkler system.....	113.20-3
Branch circuits:	
Appliance.....	111.77-1
Autotransformer.....	111.20-10
General alarm.....	113.25-8
Lighting. (See Lighting branch circuits)	
Motor. (See Motor branch circuits)	
Steering gear. (See Steering gear)	
Ungrounded conductors.....	111.50-3(f)
Vital equipment.....	111.60-9
Buses, switchboard.....	111.30-19
Busways.....	111.59
Bus-tie, main/emergency.....	112.05-3

C

Cable:	
Application.....	111.60-3
Armored.....	111.05-7, 111.105-17
Connections.....	111.60-17
Construction.....	111.60-1
Fiber optic.....	111.60-6
Flexible cords and cable.....	111.60-13
Generator.....	111.12-9
Grounding of armor.....	111.05-7
In battery rooms.....	111.15-20
In hazardous spaces.....	111.105-15, 111.105-17, 111.105-31
Inspection and testing.....	111.60-1, 111.60-13(a), 111.60-21
Installation.....	111.60-5
Metal-clad (type MC) cable.....	111.60-23
Segregation of vital circuits.....	111.60-9
Specialty cable for communication and RF applications.....	111.60-2

Subchapter J Index

Splicing.....	111.60-13, 111.60-17, 111.60-19
Wire	111.30-19, 111.60-11
Calculation of short-circuit current.....	111.52
Cargo spaces:	
Emergency lighting	112.15-1(f)
Central control panel, definition of.....	111.99-3
Chargers, battery	111.15-30
Chemicals, vessels carrying.....	111.105
Circuit:	
Branch. (See Branch circuits)	
Lighting. (See Lighting branch circuit)	
Motor. (See Motor circuits)	
Vital, segregation of.....	111.60-9
Circuit breakers:	
Accessibility.....	111.50-5(b)
Circuit connections	111.55-3
Coordination	111.51
Construction.....	111.54-1
Disconnecting and guarding	111.50-9
Draw-out type	111.30-25(b)(2), 111.30-27(b)(2)
Enclosure.....	111.50-7
Generator protection.....	111.12-11, 111.30-25(b), 111.30-27(b)
Grounded conductors.....	111.50-3(g)
In parallel.....	111.50-3(d)
Installation.....	111.51-3
Interrupting rating.....	111.54-1(a)(3)
Location in circuit	111.50-5(a)
Setting or rating	111.50-3
Ungrounded conductors	111.50-3(f)
Coal, vessels carrying.....	111.105-35
Coastwise vessel, definition of.....	110.15-1(b)
Codes, references and standards.....	110.10
Combustible liquid, vessels carrying	111.105-29
Commandant, definition of.....	110.15-1(b)
Communication systems:	
Engine order telegraph. (See Engine order telegraph)	
Environmental tests.....	113.05-7
Essential	112.15-1(h)
Sound powered telephone. (See Sound powered telephone)	
Compass, gyro:	
Communication.....	113.30-5(b)
Power supply.....	112.15-5(j)
Compressed air starting.....	112.50-7
Conductors:	
Lightning ground.....	111.05-9
Systems ground.....	111.05-31
Connection boxes, shore power.....	111.83
Contact makers, general emergency alarm system:	
General.....	113.25-11
Location	113.25-5
Controllers, motor. (See Motor controller)	
Cooking equipment.....	111.77-3
Coordination of overcurrent protective devices.....	111.51
Cord, flexible.....	111.60-13
Corrosion-resistant material or finish:	
Definition	110.15-1(b)
Requirements.....	111.01-11

46 CFR Ch. I (10–1–06 Edition)

Corrosive location, definition of	110.15-1(b)
Crew spaces:	
Emergency lighting.....	112.15-1(c)
Lighting.....	111.75-15(c)
Current-carrying capacity:	
Cable.....	111.60-1
Portable cords.....	111.60-13(c)
Wire.....	111.60-11(c)

D

Dead ship condition:	
Definition.....	110.15-1(b)
Start up	111.10-7
Definitions.....	110.15-1
Depth sounder, power supply for.....	112.15-5(j)
Detector systems:	
Fire. (See Fire detecting and alarm systems)	
Gas. (See Gas detection systems)	
Smoke. (See Smoke detector systems)	
Diesel engine driven emergency generator sets	112.50
Disconnecting means:	
Control, interlock, or indicator circuits	111.70-7(d)
Generators	111.30-25(b), 111.30-27(b)
Motor circuits.....	111.70-1
Overcurrent devices.....	111.50-9
Distribution panels. (See Panelboards)	
Door holding and release systems	111.99
Doors, watertight, electric power-operated.....	111.97
Drawings, submittal requirements.....	110.25
Drilling units:	
Hazardous locations.....	111.105-33
Industrial systems	111.107
Dripproof, definition of	110.15-1(b)
Dumbwaiters	111.91
Duty cycle.....	111.25-15

E

Electric air heaters	111.87
Electric cooking equipment	111.77-3
Electric oil immersion heaters.....	111.85
Electric power-operated lifeboat winches	
Applicability.....	111.95-1
General requirements	111.95-3
Wiring.....	111.95-7
Electric power-operated watertight door systems. (See Watertight door systems)	
Electric propulsion:	
General.....	111.35
Grounding	111.05-21(a)
Electric starting, emergency generator prime mover	112.50-5
Electric steering gear. (See Steering gear)	
Electrical installations in hazardous locations:	
Agricultural products, vessels carrying	111.105-45
Applicability	111.105-1
Approved equipment	111.105-7
Battery rooms	111.105-41
Belt drives	111.105-27
Coal carriers	111.105-35

Subchapter J Index

Combustible liquid cargo carriers	111.105-29, 111.105-31
Explosionproof equipment	111.105-9
Flammable anesthetics	111.105-37
Flammable cargo carriers	111.105-31
Fuel, vessels carrying vehicles with.....	111.105-39
General requirements	111.105-3
Industrial systems	111.107
Intrinsically safe systems	111.105-11
Liquefied gas carriers	111.105-32
Mobile offshore drilling units.....	111.105-33, 111.107
Paint stowage or mixing spaces	111.105-43
RO/RO vessels, additional requirements for	111.105-40
Switches	111.105-19
Ventilation ducts.....	111.105-21
Wiring methods	111.105-15, 111.105-17
Electrical supply: Voltage and frequency	111.01-17
Elevators, dumbwaiters, and escalators:	
General	111.91
Power supply	112.15-5(b)
Embarkation station:	
Definition	110.15-1(b)
Emergency lighting.....	111.75-16, 112.43-11
Emergency diesel and gas turbine: Engine driven generator sets.....	112.20-10
Emergency lighting and power system	112
Alternating-current temporary source	112.40
Automatic emergency lighting and power system, definition	112.01-10
Branch circuits	111.75-15(a)
Cable in engineroom	112.05-5(f)
Compartment protection.....	112.05-5(e)
Control of lights	112.43-1, 112.43-5
Definitions	112.01
Diesel driven emergency source of power	112.20-10
Emergency loads on systems without a temporary emergency power source.....	112.15-10
Emergency power source	112.05-5
Emergency system having an automatic starting diesel engine or gas turbine-driven emergency power source as the sole emergency power source.....	112.25
Failure of power from the normal source	112.20-5
Final emergency loads.....	112.15-5
Final emergency power source, definition	112.01-20
Gas turbine	112.20-10
Generators	112.50-1
Lighting feeder. (See Lighting)	
Main-emergency bus-tie	112.05-3
Manual control	112.35-5
Manual emergency lighting and power system, definition.....	112.01-5
Marking of emergency lights	112.15-1(d)
Potential of final emergency power source.....	112.20-15
Source of supply	112.05-5
Storage batteries:	
Capacity	112.05-5(a), 112.55-15
Charging.....	112.55-10
Indication of discharge	112.45-1
Installation.....	112.55
Maximum initial voltage	112.55-5
Visible indicators.....	112.45-1

46 CFR Ch. I (10–1–06 Edition)

Switchboard	111.30-29, 112.05-5(g), 112.05-5(h)
Temporary emergency power source:	
Definition	112.01-15
Requirements	112.37
Temporary emergency loads.....	112.15-1
Visible indicators	112.45-1
Emergency squad:	
Definition	110.15-1(b)
Equipment locker, communication.....	113.30-5(d)
Enclosure and protection	111.01-3, 111.01-5, 111.01-9, 111.01-11
Engine order telegraph system:	
Definitions.....	113.35-1
Electric type.....	113.35-5
General requirements	113.35-3
Indicator, definition	113.35-1
Mechanical type	113.35-9
Navigating bridge control.....	113.35-17
Transmitter, definition	113.35-1
Engineers alarm	113.27
Engineroom:	
Communication required.....	113.30-5(a)
Emergency lighting.....	112.15-1(b)
Lighting.....	111.75-1(b), 111.75-15(b)
Equalizer buses	111.12-11(i)(2)
Equalizer poles	111.12-11(i)(1)
Equipment grounding conductors	111.05-33
Equivalents.....	110.20-1
Escalators. (See Elevators)	
Escape trunks, emergency lighting of.....	112.15-1(c)
Excitation, generator	111.12-3
Exit lights:	
Construction	111.75-15(e)
Power source	112.15-1(d)
Explosion-proof equipment	111.105-9

F

Fan, nonsparking, definition.....	110.15-1(b)
Fans in hazardous locations	111.105-21
Fault current calculations. (See Short-circuit calculations)	
Feeders, general alarm system.....	113.25-8
Final emergency loads.....	112.15-5
Final emergency power source, definition of	112.01-20
Fire detecting and alarm system:	
Power supply	112.15-1(p), 113.10-9
Requirements	113.10
Fire door holding and release systems:	
Applicability.....	111.99-1
Definitions.....	111.99-3
General	111.99-5
Source of power.....	112.15-1(k)
Fire pumps, emergency: Source of power	112.15-5(e)
Fixture wire. (See Wire)	
Fixtures. (See Lighting)	
Flammable anesthetics	111.105-37
Flammable cargo carriers	111.105-31, 111.105-32
Flashing red lights, general emergency alarm system	113.25-10
Flashpoint:	

Subchapter J Index

Definition	110.15-1(b)
Fuel for emergency generator	112.50-1(b)
Flexible cord	111.60-13
Floodlights, lifeboat. (See Lifeboat floodlights)	
Frequency: Standard	111.01-17
Fuel-oil pumps, remote control	111.103-9
Fuses:	
Accessibility	111.50-5(b)
Circuit connections	111.55-3
Coordination	111.51
Disconnecting and guarding	111.50-9
Enclosures	111.50-7
General emergency alarm system	113.25-16
General requirements	111.53-1
Grounded conductors	111.50-3
In parallel	111.50-3(d)
Location in circuit	111.50-5(a)
Rating	111.50-3(a), 111.75-5(d)
Ungrounded conductors	111.50-3(f)

G

Galley, emergency lighting of	112.15-1(f)
Gas detection systems	111.105-31(n)(2), 111.105-39(b), 111.105-40(c)
Gasoline, in vehicles	111.105-39
General emergency alarm systems:	
Alarm signals	113.25-9, 113.25-12
Applicability	113.25-1
Barges	113.25-1, 113.25-25, 113.25-30
Cable entrances	113.25-14
Contact makers	113.25-5, 113.25-11
Distribution of feeder and branch circuits	113.25-8
Distribution panels	113.25-15
Flashing red lights	113.25-10
Fuses	113.25-16
General requirement	113.25-3
Marking	113.25-20
Overcurrent protection	113.25-7
Power supply	113.25-6
Generator:	
Cable	111.12-9
Construction	111.12
Emergency	111.12, 112.50
Excitation	111.12-3
Grounding	111.05-17
Indicating instruments	111.30-25, 111.30-27, 111.30-29
Neutral grounding	111.05-17
Overcurrent protection	111.12-11
Parallel operation	111.12-7
Prime movers for	111.12-1
Protection	111.12-11
Requirement	111.10-3, 112.05-5
Switchboard equipment	111.30-25, 111.30-27, 111.30-29
Testing	111.12-5
Voltage regulation	111.12-7
General emergency alarm signals	113.25-9
Great Lakes vessel, definition of	110.15-1(b)
Ground detection:	

46 CFR Ch. I (10–1–06 Edition)

Dual voltage direct current systems	111.05-29
General	111.05-21
Location	111.05-23
Requirement	111.05-21
Switchboards	111.30-25(e), 111.30-27(e), 111.30-29(g), 111.30-29(h)
Ungrounded systems	111.05-25
Grounded conductors:	
Emergency switchboard bus-tie	111.05-17
Overcurrent device	111.05-37
Grounded systems	111.05
Grounding:	
Belt drive systems	111.105-27
Cable metallic covering	111.05-7
Conductors, equipment	111.05-33
Conductors, system	111.05-31
Equipment	111.05-3
Generation system	111.05-17
Hull return	111.05-11
Masts	111.05-9
Neutral	111.05-15
Purpose	111.05-1
Receptacles	111.79-3
System	111.05-11, 111.05-13, 111.05-17, 111.05-19
Tank vessels	111.05-19
Group control panels. (See Motor control centers)	
Gyro compass. (See Compass, gyro)	

H

Hazardous locations. (See Electrical installations in hazardous locations)	
Heater circuits	111.70-5
Heating equipment, air	111.87
Hospital	111.105-37
Hull return	111.05-11
Hydraulic starting, emergency generator prime mover	112.50-3

I

Illumination	111.75
Immersion heaters	111.85
Inclination of the vessel	111.01-19
Industrial systems	111.107
Independent laboratory definition	110.15-1(b)
Inorganic acid carriers	111.105-31
Inspector. (See Marine inspector)	
Inspection and testing:	
General	110.30-1
Initial	110.30-3
Inspection for certification	110.30-5
Repairs or alterations	110.30-7
Institute of Electrical and Electronics Engineers (IEEE): Standards	110.10-1(b)
Instruments:	
Emergency battery charger	112.55-10(d)
Switchboards	111.30-25, 111.30-27, 111.30-29
Internal communications	113.30
Applicability	113.30-1
Locations	113.30-5
International Association of Drilling Contractors (IADC): Standards	110.10-1(b)
International Electrotechnical Commission (IEC): Standards	110.10-1(b)

Subchapter J Index

International Maritime Organization (IMO): Standards	110.10-1(b)
International Society for Measurement and Control (ISA): Standards.....	110.10-1(b)
Intrinsically safe systems	111.105-11

J

Junction boxes. (See Boxes)

L

Lampholders, connections to.....	111.75-5(e)
Lamps, portable. (See Lighting, fixtures)	
Lanterns, battery operated.....	Table 112.05-5(a), 112.39
Lifeboat receptacles. (See Survival craft floodlights)	
Lifeboat winches. (See Boat winches)	
Lighting:	
Branch circuits.....	111.75-5
Emergency system	112.43
Feeders	111.75-1
Feeders, emergency.....	112.43-15
Fixtures, general.....	111.75-20
For cargo handling rooms	111.105-31(g)
Requirements.....	111.75-15
System ground detection	111.05-21(c)
Lightning ground conductor.....	111.05-9
Lights, navigation:	
General.....	111.75-17
Power supply	112.15-1(a)
Lights, signaling:	
General.....	111.75-18
Power supply	112.15-1(m)
Liquid sulfur carriers	111.105-31
Locations: Corrosive, definition.....	110.15-1(b)
Location not requiring an exceptional degree of protection, definition of	110.15-1(b)
Location requiring an exceptional degree of protection, definition of.....	110.15-1(b)
Locking device: Panelboards	111.40-9
Lookout, communication for	113.30-5(g)
Loudspeaker system. (See Public address system)	
Low voltage release.....	111.70-3(b)
Low voltage protection	111.70-3(c)
Lube oil pumps, power supply for.....	112.15-5(g)

M

Machinery spaces:	
Emergency lighting.....	112.15-1
Lighting of	111.75-1(b), 111.75-15(b)
Machinery stop stations.....	111.103-9
Main emergency bus-tie	112.05-3
Manual emergency lighting and power system, definition of.....	112.01-5
Manual fire alarm systems.....	113.10
Marine inspector, definition of.....	110.15-1(b)
Marking:	
General emergency alarm system components.....	113.25-20
Motors	111.25-5
Masts, grounding of	111.05-9
Meters. (See Instruments)	

46 CFR Ch. I (10–1–06 Edition)

Military Specifications: Standards	110.10-1(b)
Mobile offshore drilling units: Hazardous location	111.105-33
Motor circuits:	111.70
General	111.70-1
Heater circuits	111.70-5
Low voltage protection	111.70-3(c)
Low voltage release	111.70-3(b)
Motor control centers	111.70-3
Motor controllers	111.70
Motors:	111.25
Degree of protection	111.01-9
Duty cycle	111.25-15
General requirements	111.25-1
Heaters	111.70-5
Marking	111.25-5

N

National Electrical Code (NEC). (See National Fire Protection Association)	
National Electrical Manufacturers Association (NEMA): Standards	110.10-1(b)
National Fire Protection Association (NFPA): Standards	110.10-1(b)
Naval Publications and Forms Center: Standards	110.10-1(b)
Naval Sea Systems Command: Standards	110.10-1(b)
Navigating bridge:	
Public address systems	113.50(b)
Navigation light indicator panel	111.75-17(b)
Power supply	112.43-13
Navigation lights	111.75-17
Power supply	112.15-1(a)
Neutral, grounding of	111.05-15, 111.05-17
Nonsparking fan, definition of	110.15-1(b)

O

Ocean vessel, definition of	110.15-1(b)
Oil immersion heaters	111.85
Outlet boxes:	
Cable entrances	111.81-3
General	111.81-1
Shore power	111.83
Overcurrent protection	111.50
Appliance circuits	111.77-1
Battery conductors	111.15-25
Circuit breakers	111.54
Conductors, general	111.50-3
Coordination of devices	111.51
Disconnecting and guarding	111.50-9
Enclosures for devices	111.50-7
Equipment, general	111.50-1
Fuses	111.50-3, 111.53
Generators	111.12-11
Grounded conductors	111.50-3(g)
Location of devices	111.50-5
Motors and motor circuits	111.70
Navigation lights	111.75-17
Parallel devices	111.50-3(d)
Propulsion circuits	111.35
Switchboard circuits	111.30-17
Systems integration	111.50-2

Subchapter J Index

Thermal devices	111.50-3(e)
Transformers.....	111.20-15
Ungrounded conductors	111.50-3(f)
Watertight door systems	111.97-9

P

Paint stowage or mixing spaces	111.105-43
Panelboards.....	111.40
Directory.....	111.40-11
Enclosure.....	111.40-5
Location	111.40-7
Locking device.....	111.40-9
Parallel operation of generators.....	111.12-7
Passageways, lighting of	112.15-1(c)
Plan submittals.....	110.25
Public address system:	
Applicability.....	113.50-1
Distribution of cable runs.....	113.50-20
General requirements	113.50-5
Location.....	113.50-15
Passenger vessels, additional requirements for	113.50-10
Power supply for	112.15-1(j)
Sound level requirements	113.50-15

Q

Qualified person, definition.....	110.15-1(b)
-----------------------------------	-------------

R

Radar	112.15-5(j)
Radio, power supply	112.15-5(i)
Radio direction finder, power supply	112.15-5(j)
Receptacles	111.79
Reference specifications, standards, and codes	110.10
Refrigerated spaces alarm system.....	113.45
Regulators, voltage	111.30-25(b)(5), 111.30-25(b)(6), 111.30-27(c)(2), 111.30-29(f)
Release, fire door. (See Fire door holding and release systems)	
Remote stopping systems	111.103
Machinery space ventilation.....	111.103-3
Machinery stop stations.....	111.103-9
Ventilation stop stations	111.103-7
Ventilation systems, general	111.103-1
Repairs	110.01-3
Resistors, discharge	111.30-25(c)
Reverse-power protection:	
Batteries	111.15-25
Generators	111.12-11(f)
Rheostats	111.30-25(c), 111.30-27(b)(3)
Rudder angle indicator systems	113.40
Power supply for	112.15-5(h)

S

Seals and seal fittings	111.105-17
Semiconductor rectifiers (SCR)	111.33
General	111.33-1
Propulsion systems	111.33-11
Temperature alarm.....	111.33-7, 111.33-11

46 CFR Ch. I (10–1–06 Edition)

Ventilation exhaust.....	111.33-9
Ship's service generators. (See Generators)	
Shore connection:	
Boxes.....	111.83
Pilot lights.....	111.30-25(f), 111.30-27(f)
Switch or circuit breaker.....	111.30-25(f), 111.30-27(f)
Voltmeter.....	111.30-25(f), 111.30-25(f)
Short-circuit current calculations.....	111.52
Signaling lights.....	111.75-18
Power supply.....	112.43-7, 112.43-9, 112.15-1(m)
Smoke detector systems: Power supply.....	112.15-1(n)
Sound level:	
General emergency alarm system.....	113.25-9
Loudspeakers.....	113.50-15
Sound powered telephone systems. (See Internal communications)	
Spacing. (See Accessibility)	
Splices and splicing.....	111.60-19
Sprinkler systems, automatic.....	113.20
Power supply.....	112.15-5(f)
Stairways, emergency lighting of.....	112.15-1(c)
Standards, references and codes.....	110.10-1
Starting, emergency generator prime mover.....	112.50
Steering failure alarm system.....	113.43
Steering gear room, communication with.....	113.30-5(a)(2)
Steering station, alternative, communication with.....	113.30-5(a)(3)
Storage battery. (See Batteries, storage)	
Submersible motor-driven bilge pumps.....	111.101
Power supply.....	111.101-3(f), 112.15-5(d)
Submittals.....	110.25
Survival craft floodlights:	
Branch circuits.....	112.43-11
Distribution panel.....	112.43-7
General.....	111.75-16
Receptacles.....	111.79-9, 111.79-11
Switchboards.....	111.30
Alternating-current ship's service.....	111.30-25
Buses.....	111.30-19
Construction.....	111.30-5
Direct-current ship's service.....	111.30-27
Emergency.....	111.30-29
Installation.....	111.30-1
Location.....	111.30-1
Nameplates.....	111.30-15
Propulsion.....	111.35
Protection of instrument circuits.....	111.30-17
Rear access.....	111.30-3
Switches.....	111.55
Bus sectionalizing.....	111.30-24
Circuit connections.....	111.55-3
Emergency lighting system.....	112.43-1
General.....	111.55-1
Generator.....	111.30-25(b), 111.30-27(b)
Hazardous locations.....	111.105-19
Lifeboat.....	111.95
Synchronizing lamps.....	111.30-25(d)
Synchroscope.....	111.30-25(d)

Subchapter J Index

T

Tank vessels:	
Electrical installations in hazardous locations	111.105
Grounded distribution systems	111.05-19
Telegraph, engine order. (See Engine order telegraph)	
Temperature, air heater case	111.87-3(e)
Temperature, ambient	111.01-15
Temperature alarm, SCR.....	111.33-7
Temperature ratings	111.01-15
Temperature rise:	
Lighting fixtures	111.105-31(g)(4)
Transformers	111.20-5
Temporary emergency loads.....	112.15-1
Temporary emergency power source, definition of	112.01-15
Terminations	111.60-17
Testing and inspection. (See Inspection and testing)	
Transformers.....	111.20
Autotransformers.....	111.20-10
General	111.20-1
Overcurrent protection	111.20-15
Power and lighting system	111.10-9
Temperature rise	111.20-5

U

Underwriters Laboratories, Inc. (UL): Standards.....	110.10-1(b)
Ungrounded systems, ground detection for.....	111.05-25

V

Ventilation:	
Remote stopping systems	111.103
Semiconductor rectifiers.....	111.33-5, 111.33-9
Storage batteries	111.15-10
Ventilation alarms	111.33-7, 111.105-33(f), 111.105-39
Vessels carrying coal	111.105-35
Visible indicators	112.45-1
Vital circuits, segregation of.....	111.60-9
Vital equipment, protection of.....	111.51-3
Voltage regulation, generators.....	111.12-7
Voltages, standard	111.01-17
Voltmeters:	
Generator	111.30-25(b)(5), 111.30-27(c), 111.30-27(d), 111.30-27(g)
Shore power.....	111.30-25(f), 111.30-27(f)

W

Waterproof equipment	111.01-9
Waterproof, definition of.....	110.15-1(b)
Watertight, definition of	110.15-1(b)
Watertight door systems.....	111.97
Applicability.....	111.97-1
Distribution.....	111.97-7
Electric and hydraulic power supply	111.97-5
General requirements	111.97-3
Lighting	112.15-1(c), 112.15-1(e)
Overcurrent protection.....	111.97-9
Power source	112.15-1(i)

46 CFR Ch. I (10–1–06 Edition)

Watertight equipment	111.01-9
Fire detection and alarm system.....	113.10-7
General emergency alarm systems.....	113.25-11(a), 113.25-14, 113.25-15(a)
Internal communications.....	113.30-25
Outlet boxes	111.81
Receptacles.....	111.79-1
Rudder angle indicator	113.40-10(b)
Sound powered telephone systems	113.30-25
Sprinkler systems.....	113.20-3
Wattmeter, generator	111.30-25(d)(2)
Wheelhouse. (See Navigating bridge)	
Whistle Operators.....	113.65
Source of power	112.15-1(o)
Winches, boat, electric-power operated.....	111.95
Wire:	
General.....	111.60-11
Switchboard.....	111.30-19(b)
Wiring materials and methods:	
General	111.60
Methods hazardous locations.....	111.105-17
Working space, switchboard	111.30-1
Emergency lighting	112.15-1(c), 112.15-1(f)